



## WINDOW RECEPTION AND STORAGE

Check the condition of the packaging immediately upon receipt of the shipment. Photograph possible product damage. Visible transport damage must be recorded in the consignment note.

The carrier is not liable for transport damage that is not recorded in the consignment note.

The window package is protected with a plastic film for short-lived (approx. 2-3 weeks: a) site storage. Any tears and holes in the packaging should be patched with plastic or tape. When storing, windows should be placed on a flat and dry surface to prevent them from tipping over and getting humidity.

Do not store anything in front of, behind or attached to the window, as sun may cause a heat shock to the glass, which may cause the glass to break.

When the plastic cover is opened, any loose parts, such as the safety ropes of the bottom-hinged ventilation window, must be collected and properly installed.

**Please note! Defective or damaged product must not be installed without the permission of the manufacturer.**

Comments must be made within seven (7) days at (RYHT 2000). In case of transport damage, see the instructions in the consignment note.

## WINDOW INSTALLATION INSTRUCTIONS

Watch the installation video on our website: [www.piklas.fi](http://www.piklas.fi) ➡ Ikkunat ➡ Asennan ikkunat itse

1. Attach screws or wedges to the bottom of the opening, on top of which you can install the windows horizontally.
2. Remove the inner frame from the window to be installed and, if necessary, drill mounting holes in the frame with a wood drill.
3. Lift and centre the frame in the window opening.
4. Mount the window to the frame structure with 6x70-120mm wood screws. Adjust the frame to the cross dimension by tightening the screws. Use wedges so that the screw does not skew the frame.
5. Cover the screw holes with cover plugs. Please note! Cover plugs are not automatically included in the delivery.
6. Refit the inner frame, check the running clearance and adjust if necessary. The adjustment of the frame is done by turning the hinges clockwise or counter-clockwise.
7. Insulate the sides of the window with either mineral wool or joint insulation. Note the swelling of the joint insulation according to the product description of the insulation.
8. Measure the water damper, cut it to the correct length and fasten. Note a sufficient inclination (at least 1:3) and a sufficient distance from the front edge of the water damper to the wall (at least 30 mm) to prevent water from dripping into the wall.

